

Pin Name (1)	144-Pin TQFP	208-Pin PQFP	240-Pin PQFP (2), (3)	256-Pin FineLine BGA	484-Pin FineLine BGA
MSEL0 (4)	77	108	124	P1	U4
MSEL1 (4)	76	107	123	R1	V4
nSTATUS (4)	35	52	60	T16	W19
nCONFIG (4)	74	105	121	N4	T7
DCLK (4)	107	155	179	B2	E5
CONF_DONE (4)	2	2	2	C15	F18
INIT_DONE (5)	14	19	26	G16	K19
nCE (4)	106	154	178	B1	E4
nCEO (4)	3	3	3	B16	E19
nWS (6)	142	206	238	B14	E17
nRS (6)	141	204	236	C14	F17
nCS (6)	144	208	240	A16	D19
CS (6)	143	207	239	A15	D18
RDYnBUSY (6)	11	16	23	G14	K17
CLKUSR (6)	7	10	11	D15	G18
DATA7 (6)	116	166	190	B5	E8
DATA6 (6)	114	164	188	D4	G7
DATA5 (6)	113	162	186	A4	D7
DATA4 (6)	112	161	185	B4	E7
DATA3 (6)	111	159	183	C3	F6
DATA2 (6)	110	158	182	A2	D5
DATA1 (6)	109	157	181	B3	E6
DATA0 (4), (7)	108	156	180	A1	D4
TDI (4)	105	153	177	C2	F5
TDO (4)	4	4	4	C16	F19
TCK (4)	1	1	1	B15	E18
TMS (4)	34	50	58	P15	U18
TRST (4)	(8)	51	59	R16	V19
Dedicated Inputs	54, 56, 124, 126	78, 80, 182, 184	90, 92, 210, 212	B9, E8, M9, R8	E12, H11, R12, V11
Dedicated Clock Pins	55, 125	79, 183	91, 211	A9, L8	D12, P11
GCLK1 (9)	55	79	91	L8	P11
Lock (10)	42	62	73	P12	U15
DEV_CLRn (5)	122	180	209	D8	G11
DEV_OE (5)	128	186	213	C9	F12
VCCINT (2.5 V)	6, 25, 52, 75, 93, 123	6, 23, 35, 43, 76, 106, 109, 117, 137, 145, 181	5, 27, 47, 96, 122, 130, 150, 170	E11, F5, F7, F9, F12, H6, H7, H10, J7, J10, J11, K9, L5, L7, L12, M11, R2	C11, C15, H14, J8, J10, J12, J15, L9, L10, L13, M10, M13, M14, N12, P8, P10, P15, R14, V5, W21, Y8, AA12
VCCIO (2.5 or 3.3 V)	5, 24, 45, 61, 71, 94, 115, 134	5, 22, 34, 42, 66, 84, 98, 110, 118, 138, 146, 165, 178, 194	16, 37, 57, 77, 112, 140, 160, 189, 205, 224	D12, E6, F8, F10, G6, G8, G11, H11, J6, K6, K8, K11, L10, M6, N12	A6, A13, B5, E1, G1, G15, H9, H20, J11, J13, K9, K11, K14, K20, L14, M9, N3, N9, N11, N14, N20, P13, R1, R9, T3, T15, T22, V22, AB13
VCC_CKCLK (11)	53	77	89	L9 (10)	P12

Pin Name (1)	144-Pin TQFP	208-Pin PQFP	240-Pin PQFP (2), (3)	256-Pin FineLine BGA	484-Pin FineLine BGA
GNDINT	15, 16, 40, 50, 58, 66, 84, 85, 103, 104, 127, 129, 139	20, 21, 32, 33, 48, 49, 59, 72, 82, 91, 123, 124, 129, 130, 151, 152, 171, 185, 188, 201	10, 22, 32, 42, 52, 69, 85, 104, 125, 135, 145, 155, 165, 176, 197, 216, 232	E5, E12, F6, F11, G7, G9, G10, H8, H9, J8, J9, K7, K10, L6, L11, M5, M12	A1, A8, A22, B1, B2, B17, B21, B22, C2, C21, E21, G3, G21, H2, H8, H15, J9, J14, J20, K3, K10, K12, K13, L11, L12, M11, M12, M20, N10, N13, P9, P14, R8, R15, R22, T1, V3, W20, Y1, Y2, Y3, Y21, Y22, AA1, AA6, AA22, AB11, AB16
GNDIO	—	—	—	—	—
GND_CCLK (11)	57	81	93	T8 (11)	W11
No Connect	—	—	—	—	A2, A3, A4, A5, A7, A9, A11, A12, A14, A15, A20, A21, B3, B4, B9, B10, B12, B16, B19, B20, C1, C6, C9, C10, C12, C13, C14, C16, C17, C22, D1, D2, D3, D20, D21, E2, E3, E20, E22, F1, F2, F20, F21, G2, G20, G22, J1, J2, J3, J21, K2, K22, L1, L2, L20, L22, M2, M3, M22, N1, N2, N21, N22, P3, P20, P21, P22, R2, R3, R21, T2, T20, T21, U1, U2, U3, U20, U21, U22, V2, V20, W1, W2, W22, Y4, Y9, Y12, Y13, Y16, Y19, Y20, AA2, AA3, AA4, AA9, AA11, AA13, AA15, AA21, AB1, AB2, AB3, AB4, AB5, AB7, AB8, AB9, AB12, AB15, AB17, AB18, AB19, AB20, AB21, AB22
Total User I/O Pins (12)	102	147	189	191	254

Notes:

- (1) All pins that are not listed are user I/O pins.
- (2) EPF10K50E, EPF10K100E, and EPF10K100B devices are pin-compatible with EPF10K130E devices in the same package if pins 20, 76, and 159 are connected to VCCINT. The MAX+PLUS II software performs this function automatically when future migration is set.
- (3) EPF10K50E, EPF10K100E, and EPF10K100B devices are pin-compatible with EPF10K200E devices in the same package if pins 20, 40, 76, 139, 159, 187, and 225 are connected to VCCINT. The MAX+PLUS II software performs this function automatically when future migration is set.
- (4) This pin is a dedicated pin; it is not available as a user I/O pin.
- (5) This pin can be used as a user I/O pin if it is not used for its device-wide or configuration function.
- (6) This pin can be used as a user I/O pin after configuration.
- (7) This pin is tri-stated in user mode.
- (8) The optional JTAG pin TRST is not used in the 144-pin TQFP package.
- (9) This pin drives the ClockLock and ClockBoost circuitry.
- (10) This pin shows the status of the ClockLock and ClockBoost circuitry. When the ClockLock and ClockBoost circuitry is locked to the incoming clock and generates an internal clock, LOCK is driven high. LOCK remains high if a periodic clock stops clocking. The LOCK function is optional; if the LOCK output is not used, this pin is a user I/O pin.
- (11) This pin is the power or ground for the ClockLock and ClockBoost circuitry. To ensure noise resistance, the power and ground supply to the Clock Lock and Clock Boost circuitry should be isolated from the power and ground to the rest of the device. If the ClockLock or ClockBoost circuitry is not used, this power or ground pin should be connected to VCCINT or GNDINT, respectively.
- (12) The user I/O pin count includes dedicated inputs, dedicated clock inputs, and all I/O pins.